



Please consult the drawing for proper installation

1. Apply tie rod through top base (spider) center hole
2. Apply tie rod through the column
3. Place top base (spider) on hard surface with tie rod in upright position.
4. Apply tie rod through the center hole of the bottom base
5. Apply the washer and the nut. Center all the components and tighten securely.
6. Apply the glides (levellers)



To attach table top to the base please follow these guidelines

Top base (Spider)
 Screw hole size 1/4"
 Lip thickness 1/4"
 For table top 1" thick
 suggested screw size
 3/16" x 1" max length.
 Please use self threading wood screw.
 For table tops
 1" and thicker suggested
 screw size 3/16" x 1" min
 to a maximum screw size @
 1/4" less than thickness of
 the table top.